

## Freerider™ Cordless Robotic Pool Cleaner


Model: FR200

TYPE ET35

### **⚠ WARNING**

This Quick Start Guide contains essential installation and startup instructions. For additional operation, maintenance, and troubleshooting instructions, please refer to the complete Owner's Manual. Read the complete manual and all safety warnings before commencing installation. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

## Package Contents



Cleaner




Charger



Hook  
(fits standard pool pole)

## Cleaner Status and Information LEDs



Status LED:



After 8 days of inactivity, the cleaner enters Deep Sleep Mode. Plug in the power cord to wake up the cleaner.

### While Charging

- Solid Green: Fully Charged
- Blinking Green: Ready to run a full cycle (1 h 30 min)
- Blinking Orange: Low Battery, charging
- Blinking Red: Error

### Ready to Start (unplugged)

- Solid Green: Ready to immerse
- Solid Orange: Low Battery
- Blinking Orange: Very low battery, cannot run
- Blinking Red: Error

### During Cycle

- Solid Green: In progress
- Solid Orange: Low Battery
- Blinking Red: Error
- ☒ Off: Cycle complete


# 1 Setup and Charging

Fully charge the cleaner before the first cleaning.

- Open protective cap covering charging port
- Ensure charging port is dry
- Connect to an indoor RCBO outlet
- Only use the charger supplied
- Charging Temperature Range: 5°C - 43°C



## ⚠ WARNING


Do not use extension cords when charging.



## 2 Start Cleaning

 < 4h

 GREEN Blinking (< 3h) = Ready to run full cycle  
 GREEN Solid = Fully Charged




**(a)** Replace the protective cap over the charging port.


**(b)** Start the cleaner. Slide the power switch down and release.

**(c)** Submerge the cleaner vertically.


**(d)** Wait for bubbles to stop completely, then let the cleaner sink to the bottom of the pool. Cleaning cycle will start as soon as the cleaner detects the pool floor.




## 3 Remove from Pool - Using the Hook



**(a)** Attach the hook provided to a standard pool pole (not included).



**(b)** Secure the hook to the cleaner handle and lift to the surface.





**(c)** Remove the cleaner from the water by the handle and drain the cleaner.

# 4

## Cleaning and Storage

- Remove the filter canister and rinse.



- **IMPORTANT: Dry the cleaner before charging.**
- Charge after each use and store out of direct sunlight.
- Replace the protective cap when cleaner is not charging.
- Fully charge cleaner before winterizing. Do not leave cleaner drained of charge for excessive periods of time.



For complete instructions and troubleshooting steps, please read the owner's manual.



**A Fluidra Brand** | [Zodiac.com.au](http://Zodiac.com.au) | [Zodiac.co.nz](http://Zodiac.co.nz)

Fluidra Group Australia Pty Ltd | 1 Herbert Place, Smithfield NSW 2164, PO Box 7238 Wetherill Park NSW 1851, Australia  
ABN: 87 002 641 965 | 1300 186 875

Fluidra NZ Ltd | 13 Douglas Alexander Parade | Rosedale Auckland 0632, New Zealand

NZBN: 942 903 181 70759 | 0800 807 665

©2025 ZODIAC® is a registered trademark of Zodiac International S.A.S., used under license.

H0893000\_REVA